

RIA Diagnostics Development at Argonne

Richard Pardo, Spokesperson

For

P.N. Ostroumov


S. I. Sharamentov

N. Vinogradov

G. P. Zinkann

B.E. Clifft

(paper 2.4.4)



Argonne National Laboratory



*A U.S. Department of Energy
Office of Science Laboratory
Operated by The University of Chicago*



RIA Diagnostics Development at Argonne

Driver Linac: High Power, High Energy LINAC

- **Low beam losses required in linac**
 - ✓ Deliver required currents to achieve beam power goals
 - ✓ Typical 1 W/m losses in high energy portions to allow easy maintenance
- **Multiple charge-state acceleration**
 - ✓ Requires low emittance growth
 - ✓ Precise tune matching
 - ✓ Removal of unused charge states at proper location

RIA Diagnostics Development at Argonne

RIB Linac: Low Intensity, High Precision LINAC

- **Low beam losses required**
 - ✓ **Efficient use of produced RIBs**
- **Low-emittance high-quality beam**
- **Possible multiple charge-state acceleration**
- **Beam current spans broad range: 1 to 10^{10} pps**

These goals, require a well planned diagnostics system.

RIA Diagnostics Development at Argonne

Diagnostics Requirements

➤ Longitudinal Diagnostics

- ✓ **Beam phase (know to $\sim 1^\circ$)**
- ✓ **Energy**
 - **Time-of-flight (velocity $\rightarrow E/A$)**
 - **Absolute total energy to verify beam species**
- ✓ **Bunch shape and size**
- ✓ **Longitudinal emittance**

➤ Transverse Diagnostics

- ✓ **Beam position (know to ~ 0.1 mm)**
- ✓ **Size**
- ✓ **Emittance**

RIA Diagnostics Development at Argonne


Diagnostic Development Activities at Argonne

- **Beam phase detection with a SC resonator**
- **Bunch length measurement**
- **Beam profile monitor for weak beams**

ATLAS has proven to be a valuable test bed for diagnostic developments

RIA Diagnostics Development at Argonne


Beam phase detection with a SC resonator



- **Heavy-ion LINACs need a range of velocity profiles**
 - ✓ Optimum acceleration over a wide q/m range.
 - *ATLAS q/m range is 0.1 to 0.5.*
 - *RIA Driver q/m range is 0.12 to 1.0.*
- **Little room for diagnostics**
 - ✓ Closely spaced lattice in low-energy section required
 - *Low emittance growth*
 - *Low beam losses*

RIA Diagnostics Development at Argonne

Beam phase detection with a SC resonator




➤ **Features of the Resonant Pickup**

- ✓ Turns every accelerating cavity into a beam phase monitor
- ✓ Less sensitive to beam steering
- ✓ Less sensitive to beam defocusing with energy change
- ✓ Good centroid time accuracy: ≤ 1 degree
- ✓ Energy measurement from phase shift possible
- ✓ Phase width from normalized amplitude (in principle)



RIA Diagnostics Development at Argonne

Beam phase detection with a SC resonator



- Induced RF Field from beam:
 - ✓ 4-5 kV/m per μA
- Resonator must operate in order to match beam frequency
- Slow rotation of operating field allows phase of beam-induced field to be extracted

$$A_{\Sigma}(t) \approx A_{rf} (1 + p \cos(\phi_{rf} - \phi_b))$$



RIA Diagnostics Development at Argonne

Beam phase detection with a SC resonator

Summary

The Resonant Beam Pickup Method has been developed at ATLAS using resonators similar to those planned for the low-velocity section of RIA.

The technique has been implemented for the low-velocity resonators in ATLAS.

Fully automated data acquisition being developed.

RIA Diagnostics Development at Argonne


Beam Bunch Length Measurement

➤ Important for low-emittance beam tuning

- ✓ **Based on time distribution of secondary electrons**
 - **Produced by beam striking thin vertical wire**
 - **Electrons accelerated, focused and RF swept onto detector**
 - **Amplified by microchannel plate detector**
 - **Light from scintillator response to electrons**
 - **Measured by CCD camera interfaced to computer**

RIA Diagnostics Development at Argonne

Beam Bunch Length Measurement



$$\Delta U_{st} + U_{RF} \sin(n\omega t + \varphi_0)$$


$$\Delta U_{st} \text{ -steering voltage}$$

$$U_{RF} \sin(n\omega t + \varphi_0) \text{ -deflecting voltage}$$



RIA Diagnostics Development at Argonne

Beam Bunch Length Measurement

Bunch image without RF power
in the deflector



Typical bunch image on the
phosphor screen




Bunch shape for 185 MeV $^{54}\text{Fe}^{16+}$ beam

RIA Diagnostics Development at Argonne


Beam Bunch Length Measurement

Longitudinal emittance measurements

Beam energy as a function of RF field phase in the last Booster resonator for 397 MeV



Measurement of longitudinal emittance for 153 MeV $^{16}\text{O}^{8+}$ beam




Summary:

The BSM works and allows measurement of the bunch shape, longitudinal emittance and another characteristics of heavy ion beams in CW mode with 20 psec resolution

RIA Diagnostics Development at Argonne

Beam Profile Monitor for Low Intensity Radioactive Beams Sensitive at Intensities $\leq 10^3$ pps





RIA Diagnostics Development at Argonne


Beam Profile Monitor for Low Intensity Radioactive Beams

Profile monitor covers a dynamic range: $>10^6$

Krypton beam, 1 MeV,
 $\sim 10^{10}$ pps



Krypton beam, 1 MeV,
 $\sim 2 \cdot 10^4$ pps



RIA Diagnostics Development at Argonne

Additional R&D Diagnostics Needs

- **Driver beam position monitors**
- **Beam halo detector**
- **Develop and test compact diagnostic box**
 - **Intercryostat space limited**
 - **Diagnostics needed**
 - **Position monitor**
 - **Phase detector**
 - **Current toroid**
 - **Wire scanner**
- **High-Accuracy Beam Energy Determination for RIBs**
 - **Time-of-flight velocity measurement**
 - **Phase and energy control**