



Development of the Fragment Separator **Designs for RIA**

Brad Sherrill, Michigan State University


with D.J. Morrissey, M. Amthor, and O. Tarasov

Overview of the Fragment Separation Technique


The NSCL Coupled Cyclotron Facility – A1900 Separator

8 msr
 $\Delta p = 5\%$

^{86}Kr 140 MeV/u



Sample Data from the A1900



140MeV/u

^{86}Kr

8 msr

5%

The NSCL has Extensive Experience in Separator Design



- The **A1200** separator was completed in 1989 and was the heart of the NSCL radioactive beam program for 10 years. RNB experiments were more than 60% of the experimental program.

Sherrill, Morrissey, Nolen, Winger NIM B56 (1993)

- The **A1900** separator was designed to be optimized for the Coupled Cyclotron Facility. It was completed in 2001.

Morrissey, Sherrill, Steiner, Stolz, Wiedenhoever NIM B204 (2003)

- The **A1900** will be a testing ground for RIA fragment separator concepts.

LISE – Necessary Tool for RIA Separator Design

LISE 6.2.21

O. Tarazov, D. Bazin


Allows a full first-order simulation of fragment separator designs including momentum compression and stopping in gas.

To Do List:

Verify current code


Fission

Monte Carlo



Yield vs. Fragment Separator Momentum Acceptance


^{78}Ni production from $^{86}\text{Kr}+^9\text{Be}$ fragmentation




[LISE 5.9](#)

Production from secondary reactions are not included.

Yields for Projectile Fission (Schematic Model)



Energy Dependence of RI Production: RIA Example




The turn over point depends on the fragment separator acceptance.

A smaller acceptance fragment separator produces a later turnover.

Basic Design Goals for the RIA Separators

- Two Separators are needed in the RIA concept
 - **High acceptance** (12%, 10 msr) to feed ions into the gas catching station.



- **Higher resolution** (higher rejection of unwanted fragments) to feed ions to the high energy experimental area: (6%, 8msr)
- **10 T-m maximum rigidity** is desirable for the most neutron rich fragments (10 Tm vs 8 Tm is a factor of 2 in yield for ^{41}Al from ^{48}Ca).
- Higher order aberrations must be kept low
 - Purity of the separated fragments
 - Stopping efficiency

Results of ion optical aberrations

Calculations done with LISE (initial spot size varied)

^{133}Te	^{134}Te
	1.02e+5 0.003%
^{132}Sb	^{133}Sb
1.01e+3 0%	2.5e+6 2.091%
^{131}Sn	^{132}Sn
2.39e+3 0.011%	5.44e+5 11.344%
^{130}In	^{131}In
3.52e+2 0.026%	4.26e+4 18.989%
^{129}Cd	^{130}Cd
6.45e+1 0.066%	3.06e+3 23.913%

3mm aberrations
76% stopped in
the cell

^{132}Sb	^{133}Sb
	1.06e+6 0.891%
^{131}Sn	^{132}Sn
	5.81e+5 12.115%
^{130}In	^{131}In
2.55e-1 0%	4.83e+4 21.563%
^{129}Cd	^{130}Cd
1.74e-2 0%	3.42e+3 26.769%

1 mm aberrations
81% stopped in
the cell



Effect of degrader errors – 2 stage separator



Wedge defect of 1.0%

Wedge defect of 0.2%

No wedge defect


¹³²Sb	¹³³Sb
	1.43e+6 1.195%
¹³¹Sn	¹³²Sn
7.1e-7 0%	8.1e+5 16.901%
¹³⁰In	¹³¹In
2.6e-1 0%	7.01e+4 31.283%
¹²⁹Cd	¹³⁰Cd
1.74e-2 0%	5.12e+3 40.005%

¹³³Te	¹³⁴Te
	6.77e+3 0%
¹³²Sb	¹³³Sb
3.65e+1 0%	2.75e+6 2.3%
¹³¹Sn	¹³²Sn
9.72e+2 0.005%	7.29e+5 15.218%
¹³⁰In	¹³¹In
3.04e+1 0.002%	5.72e+4 25.51%
¹²⁹Cd	¹³⁰Cd
2.27e+0 0.002%	4.1e+3 32.017%

¹³¹Te	¹³²Te	¹³³Te	¹³⁴Te
		7.57e+1 0%	5.66e+6 0.185%
¹³⁰Sb	¹³¹Sb	¹³²Sb	¹³³Sb
4.12e+1 0%	4.38e+5 0.045%	2.79e+6 0.748%	2.66e+6 2.23%
¹²⁹Sn	¹³⁰Sn	¹³¹Sn	¹³²Sn
3.8e+2 0%	5.42e+4 0.07%	2.53e+5 1.179%	1.74e+5 3.624%
¹²⁸In	¹²⁹In	¹³⁰In	¹³¹In
2.86e+1 0%	2.82e+3 0.045%	1.54e+4 1.136%	9.76e+3 4.355%
¹²⁷Cd	¹²⁸Cd	¹²⁹Cd	¹³⁰Cd
3.44e-1 0%	1.95e+2 0.035%	1.26e+3 1.283%	6.27e+2 4.901%
¹²⁶Ag	¹²⁷Ag		
1.35e-3 0%	1.41e+1 0.027%		

A Possible RIA Separator Configuration

The high acceptance separator could feed the gas stopping station or the high energy area.




Optical Layout of the HA Separator



Fragments after Slits H

¹³² Sb	¹³³ Sb
	1.43e+6 1.195%
¹³¹ Sn	¹³² Sn
9.81e-7 0%	8.1e+5 16.902%
¹³⁰ In	¹³¹ In
3.6e-1 0%	7.01e+4 31.284%
¹²⁹ Cd	¹³⁰ Cd
2.5e-2 0%	5.12e+3 40.006%



Beam dump area

Wedge 1

Pre-separator

Slits P

Separator

Momentum
Compensation

Wedge 2

Slits H


Gas Cell

20.000 m

¹³² Te	¹³³ Te	¹³⁴ Te
	2.69e+2 0%	
¹³¹ Sb	¹³² Sb	¹³³ Sb
4.77e+6 0.486%	7.5e+7 20.107%	1.03e+7 8.615%
¹³⁰ Sn	¹³¹ Sn	¹³² Sn
1.94e-2 0%	9.52e+5 4.43%	1.88e+6 39.226%
¹²⁹ In	¹³⁰ In	¹³¹ In
	1.74e+3 0.128%	1.01e+5 44.892%
¹²⁸ Cd	¹²⁹ Cd	¹³⁰ Cd
	1.89e+1 0.019%	6.04e+3 47.233%

Fragments after Slits P

Momentum Compression Technique



H. Weick

Range straggling can be reduced to 10% larger than the range straggling of monoenergetic ions.

H. Geissel et al. NIM A282 (89) 247


Minimum momentum compression:

$$\delta_{\min} = (Mx_0/D) (1-t/R)^{-1}$$

$$\delta_{\min} = (1.0 \cdot .2/3.0) (1.25) = .08 \%$$


Range straggling limit corresponds to .1%

Implantation Depth of Fragments – 2 stage




26-08-2003 21:45:33
L I S E ++ [C:\lise\FILES\RIA130CD2stagev2.lpp]

Implantation Depth of Fragments – 1 stage



GSI and RIKEN plan two separator stages



Pre-Separator First Order Optics





Image for beam catcher

RIA R&D Workshop August 2003

Full High Acceptance Separator First Order Layout



Fragment Separator R&D Issues

- Software development of the program LISE to be able to model all aspects of the separation and stopping process is underway and should continue.
- Preliminary designs have been investigated, but a full design of the separators is necessary to set the magnet parameters and civil construction details.
- A number of significant R&D issues remain.
 - Optimize acceptance (6% to 18%) while keeping aberrations at acceptable levels
 - Study radiation fields and damage on system components
 - Beam and fragment dump (isotope harvesting)
 - Wedge uniformity and momentum compression